
## ASSEMBLY/INSTALLATION OF THE UNI-BAND (Main Spring)


## TOP



and speed and pre-tension

(Diagram 28)

## ASSEMBLY/INSTALLATION OF THE UNI-BAND (Main Spring) to the MAIN SHAFT CLUTCH



(Diagram 59)